

RU

Памятка по сборке системы  
Wind Protection

EN


Wind Protection  
system assembly guide

FR

Fiche d'instruction d'assemblage du  
système Wind Protection



DE

Bauanleitung zum system  
Wind Protection




GR105x35IE

RG/WP






1






# 2.a

RG/WP +  
2 x (DIN 7504 ST3.9x19-O-H)





# 2.b



RG/WP +  
2 x (ISO 7050 ST3,5x19-C-H)





3.a



3.b







5

3 x (ISO 15977-4x10-AIA/St-L)

